



# Installation Guide

Unmanaged Rackmountable Switches



# About this Installation Guide

This Installation Guide describes the hardware characteristics, installation methods and the points that should be attended to during installation. This Installation Guide is structured as follows:

## Chapter 1 Introduction

This chapter describes the external components of the switch.

## Chapter 2 Installation

This chapter illustrates how to install the switch.

## Chapter 3 Connection

This chapter illustrates how to do the physical connection of the switch.

## Appendix A Troubleshooting

## Appendix B Specifications

# Audience



This Installation Guide is for:

Network Engineer

Network Administrator

# Conventions

- When using this guide, notice that features available in this series of products may vary by model and software version. Availability of the products may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience. Some models featured in this guide may be unavailable in your country or region. For local sales information, visit <https://www.mercusys.com>.
- The speed of the ports in Extend Mode will downgrade to 10 Mbps. The actual transmission distance may vary due to power consumption of PoE-powered devices or the cable quality and type.
- PoE budget calculations are based on laboratory testing. Actual PoE power budget is not guaranteed and will vary as a result of client limitations and environmental factors.
- This guide uses the specific formats to highlight special messages. The following table lists the notice icons that are used throughout this guide.

	Remind to be careful. A caution indicates a potential which may result in device damage.
	Remind to take notice. The note contains the helpful information for a better use of the product.

# Related Document

This Installation Guide is also available in PDF on our website. To obtain the latest documentation and product information, visit the official website: <https://www.mercusys.com>.

# Contents

---

Chapter 1	Introduction	1
1.1	Product Overview	1
1.2	Appearance	1
Chapter 2	Installation	5
2.1	Package Contents	5
2.2	Safety Precautions	5
2.3	Installation Tools	7
2.4	Product Installation	7
Chapter 3	Connection	9
3.1	Ethernet Port	9
3.2	SFP Port	9
3.3	Verify Installation	9
3.4	Power On	10
3.5	Initialization	10
Appendix A	Troubleshooting	11
Appendix B	Specifications	12

# Chapter 1 Introduction

## 1.1 Product Overview

The Unmanaged Switch provides you with a low-cost, easy-to-use, high-performance, seamless, and standard upgrade to improve your network to 100 Mbps or 1000 Mbps.

MS118CP/MS120GP/MS126CP/MS128GP is also a Power Sourcing Equipment (PSE\*). Some of the RJ45 ports support the Power over Ethernet (PoE\*) function, which can automatically detect and supply power to those powered devices (PDs\*) complying with IEEE 802.3af and IEEE 802.3at.



- Note:**
- \*PSE is a device (switch or hub for instance) that will provide power in a PoE setup.
  - \*PoE is a technology that describes a system to transmit electrical power, along with data, to remote devices over standard twisted-pair cable in an Ethernet network.
  - \*PD is a device powered by a PSE and thus consumes energy. Examples include powering IP telephones, wireless LAN access points, network cameras, network hubs, embedded computers, and so on.

## 1.2 Appearance

### Front Panel

The front panel of the switches are shown as the following figures.

Figure 1-1 Front Panel of MS116GS




Figure 1-2 Front Panel of MS124GS





Figure 1-3 Front Panel of MS118CP



Unmanaged Rackmountable Switches

Figure 1-4 Front Panel of MS120GP




Figure 1-5 Front Panel of MS126CP





Figure 1-6 Front Panel of MS128GP



DIP Switch Explanation

Switch	Indication
Isolation	<b>Off:</b> Ports can transmit data with each other. <b>On:</b> The isolated ports cannot transmit data with other downlink ports. They can transmit data only with the uplink ports.
Loop Prevention (For MS116GS/MS124GS)	<b>Off:</b> (default) The switch will not try to monitor or address loop-related issues. <b>On:</b> The switch will monitor and address loop-related issues within the network structure to prevent disruptions caused by redundant pathing.
Extend (For MS118CP/MS120GP/ MS126CP/MS128GP)	<b>Off:</b> For MS118CP and MS126CP, the corresponding ports run at 10/100 Mbps; for MS120GP and MS128GP, the corresponding ports run at 10/100/1000 Mbps. They only support PoE power supply up to 100 m away. <b>On:</b> The corresponding ports run at 10 Mbps and support PoE power supply up to 250 m away.
Priority (Only for MS118CP)	<b>Off:</b> All the ports transmit data with the same priority. <b>On:</b> The specific ports transmit data with a higher priority than other ports.
Recovery (For MS118CP/MS120GP/ MS126CP/MS128GP)	<b>Off:</b> The PoE Auto Recovery function is disabled. <b>On:</b> The switch will constantly detect the working status of a PoE powered device (PD). When the switch finds that the PD works abnormally, the switch will reboot it.



Note:

1. The numbers indicate the ports where the feature takes effect. For example, when Extend 1-8 is toggled to On, the Extend mode will be enabled for ports 1-8.
2. By default, ports 1-4 of MS120GP/1-8 of MS126CP/1-4 of MS128GP have higher priority than other ports in transmitting data if network congestion occurs. It is recommended to connect key network devices (network cameras, APs, etc.) to these ports.

## LED Indication

LED	Indication
Power or PWR	<b>On:</b> The switch is powered on. <b>Off:</b> The switch is powered off or power supply is abnormal. <b>Flashing:</b> Power supply is abnormal/Loop Prevention function is enabled. (Only for MS116GS/MS124GS)
1000Mbps (Only for MS116GS)	<b>On:</b> Running at 1000 Mbps. <b>Off:</b> Running at 10/100 Mbps or no device is linked to the corresponding port.
Link/Act	<b>General:</b> <b>On:</b> A device is linked to the corresponding port and running properly. <b>Flashing:</b> Transmitting or receiving data. <b>Off:</b> No device is linked to the corresponding port.  <b>Port 17–18/17F–18F of MS118CP &amp; Port 25–26/25F–26F of MS126CP:</b> <b>Green On:</b> Running at 1000 Mbps but no activity. <b>Green Flashing:</b> Running at 1000 Mbps and is transmitting or receiving data. <b>Yellow on:</b> Running at 100/10 Mbps but no activity. <b>Yellow Flashing:</b> Running at 100/10 Mbps and is transmitting or receiving data. <b>Off:</b> No device is linked to the corresponding port.  Note: The SFP ports only support 1000 Mbps SFP module connection, and they only have <b>Green On/Green Flashing/Off</b> LED indications.
PoE Status (For MS118CP/ MS120GP/ MS126CP/ MS128GP)	<b>On:</b> The port is connecting and supplying power to a PD. <b>Flashing:</b> The PoE power circuit may be in short or the power current may be overloaded or non-standard PD is connected or the amount of power of the port has exceeded the power limit. <b>Off:</b> No PD is connected to the corresponding port or no power is supplied according to the power limits of the port.
PoE Max (For MS118CP/ MS120GP/ MS126CP/ MS128GP)	<b>On:</b> The remaining PoE power is $\leq 7$ W. <b>Flashing:</b> The remaining PoE power keeps $\leq 7$ W after this LED is on for 2 minutes. <b>Off:</b> The remaining PoE power is $> 7$ W.

### 10/100/1000Mbps RJ45 Port

Designed to connect to the device with a bandwidth of 10 Mbps, 100 Mbps or 1000 Mbps. The PoE ports (ports 1–16 of MS120GP/ports 1–24 of MS128GP) can provide power for PDs.

### 10/100Mbps RJ45 Port

Designed to connect to the device with a bandwidth of 10 Mbps or 100 Mbps. The PoE ports (ports 1–16 of MS118CP/ports 1–24 of MS126CP) can provide power for PDs.


### SFP Port

Designed to install the SFP module. MS118CP/MS120GP/MS126CP/MS128GP has 2 SFP ports which support 1000 Mbps SFP module connection. On MS118CP and MS126CP, an SFP Port and the associated 10/100/1000 Mbps RJ45 Port are called a “Combo” port, which means they cannot be used simultaneously.

### ■ Rear Panel

The rear panel is shown as the following figure. Here we take MS126CP as an example.

Figure 1-7 Rear Panel



### Kensington Security Slot

Secure the lock (not provided) into the security slot to prevent the device from being stolen.



#### Note:

MS116GS and MS124GS are not designed with the kensington security slot.

### Grounding Terminal

The switch already comes with lightning protection mechanism. You can also ground the switch through the PE (Protecting Earth) cable of AC cord or with Ground Cable.

### Power Socket

Plug the female connector of the power cord directly into the power socket and plug the male connector into an AC outlet. Make sure that the voltage of the power supply meets the requirement of the input voltage (100–240 V~ 50/60 Hz).



#### Caution:


You should use the provided power cord.



## Chapter 2 Installation

### 2.1 Package Contents

Make sure that the package contains the following items. If any of the listed items is damaged or missing, contact your distributor. The figures are for demonstration only. The actual items may differ in appearance and quantity from the depicted.



### 2.2 Safety Precautions


To avoid any device damage and bodily injury caused by improper use, you should observe the following rules.

#### ■ Safety Precautions

- Keep the power off during the installation.
- Wear an ESD-preventive wrist strap, and make sure that the wrist strap has a good skin contact and is well grounded.
- Use only the power cord provided with the switch.
- Make sure that the supply voltage matches the specifications indicated on the rear panel of the switch.
- Ensure that the switch is installed in a well-ventilated environment and its ventilation hole is not blocked.
- Do not open or remove the cover of the switch.
- Before cleaning the device, cut off the power supply. Do not clean it by the waterish cloth, and never use any other liquid cleaning method.
- Place the device with its bottom surface downward.

#### ■ Site Requirements

##### Temperature/Humidity



Keep the equipment room at an appropriate level of temperature and humidity. Too much or too little humidity may lead to bad insulation, leakage of electricity, mechanical property changes, and corrosion. High temperatures may accelerate aging of the insulation materials, significantly shortening the service life of the device. To find out the best temperature and humidity conditions for the device, check the Appendix B Specifications.

### Clearness



The dust accumulated on the switch can be absorbed by static electricity and result in poor contact of metal contact points. Some measures have been taken for the device to prevent static electricity, but too strong static electricity can cause deadly damage to the electronic elements on the internal circuit board. To avoid the effect of static electricity on the operation of the switch, attach much importance to the following items:

- Dust the device regularly, and keep the indoor air clean.
- Keep the device well grounded and ensure that the static electricity has been transferred.

### Electromagnetic Interference



Electronic elements including capacitance and inductance on the device can be affected by external interferences, such as conducted emission by capacitance coupling, inductance coupling, and impedance coupling. To decrease the interferences, make sure to take the following measures:

- Use the power supply that can effectively filter interference from the power grid.
- Keep the device far from high-frequency and strong-current devices such as radio transmitting station.
- Use electromagnetic shielding when necessary.


### Lightning Protection



Extremely high voltage currents can be produced instantly when lightning occurs and the air in the electric discharge path can be instantly heated up to 20,000 °C. As this instant current is strong enough to damage electronic devices, more effective lightning protection measures should be taken.

- Ensure that the rack and the device are well earthed.
- Make sure the power socket has a good contact with the ground.
- Keep a reasonable cabling system and avoid induced lightning.
- Use the signal SPD (Surge Protective Device) when wiring outdoor.

## Installation Site



When installing the device on a rack or a flat workbench, attach much importance to the following items:

- The rack or workbench is flat, stable, and sturdy enough to support the weight of 5.5 kg at least.
- The rack or workbench has a good ventilation system. The equipment room is well ventilated.
- The rack is well grounded. Keep the device less than 1.5 meters away from the power socket.

## 2.3 Installation Tools

- Phillips screwdriver
- ESD-preventive wrist wrap
- Cables



### Note:

These tools are not included with our product. If needed, you can purchase them separately.


## 2.4 Product Installation

### ■ Desktop Installation

To install the device on the desktop, follow the steps:

1. Set the device on a flat surface which is strong enough to support the entire weight of the device with all fittings.
2. Remove the adhesive backing papers from the rubber feet.
3. Attach the rubber feet to the bottom of the switch to prevent it from slipping when placed on a desktop.

Figure 2-1 Desktop Installation




### ■ Rack Installation

To install the device in an EIA standard-sized, 19-inch rack, follow the instructions described below:


1. Check the efficiency of the grounding system and the stability of the rack.
2. Secure the supplied rack-mounting brackets to each side of the device with supplied screws, as illustrated in the following figure.

Figure 2-2 Bracket Installation



3. After the brackets are attached to the device, use suitable screws (not provided) to secure the brackets to the rack, as illustrated in the following figure.

Figure 2-3 Rack Installation



**Caution:**


- Leave 5 to 10 cm gaps around the devices for air circulation.
- Avoid placing heavy things on the device.
- Mount devices in sequence from the bottom to top of the rack and ensure a certain clearance between devices for the purpose of heat dissipation.

## Chapter 3 Connection

### 3.1 Ethernet Port

Connect an Ethernet port of the switch to the computer by RJ45 cable as the following figure shows.


Figure 3-1 Connecting the RJ45 Port



### 3.2 SFP Port

The following figure demonstrates the connection of SFP port to an SFP module.

Figure 3-2 Inserting the SFP Module



**Note:**

MS118CP/MS120GP/MS126CP/MS128GP has 2 SFP ports which support 1000 Mbps SFP module connection.

### 3.3 Verify Installation

After completing the installation, verify the following items:


- There should be 5 to 10 cm of clearance around the device for ventilation and make sure the air flow is adequate.
- The voltage of the power supply meets the requirement of the input voltage of the device.
- The power socket, device and rack are well grounded.
- The device is correctly connected to other network devices.

### 3.4 Power On

---

Plug the negative connector of the provided power cord into the power socket of the device and plug the positive connector into a power outlet as the following figure shows.

Figure 3-3 Connecting to Power Supply



**Note:**

The figure is to illustrate the application and principle. The provided plug and the socket in your region may differ from the figures above.

### 3.5 Initialization

---

After the device is powered on, it begins the Power-On Self-Test. A series of tests run automatically to ensure the device functions properly. During this time, the LED indicators will respond as follows:

1. The PWR/Power LED indicator will light up.
2. The LED indicators of all the ports will flash momentarily and then turn off again after the initialization.

## Appendix A Troubleshooting

---

### Q1. Why is the Power LED not lit?

The Power LED should be lit when the power system is working normally. If the Power LED is not lit, please check the following:

1. Ensure the AC power cord/power adapter is securely connected to both the switch and the power source.
2. Verify that the power supply's voltage meets the requirements of the switch's input voltage.
3. Confirm that the power source is on.

### Q2. Why is the Link/Act LED not lit when a device is connected to the corresponding port?

It is recommended that you check the following:

1. Make sure that the cable connectors are firmly plugged into the switch and the device.
2. Make sure the connected device is turned on and working well.
3. The cable must be less than 100 meters long (328 feet). If Extend Mode is enabled, it should be less than 250 meters (820 feet).

### Q3. Why are PoE ports not supplying power for PoE devices?

When the total power consumption of connected PoE devices exceeds the maximum, the PoE port with a smaller port number has a higher priority. The system will cut off power to the ports with larger port numbers to ensure supplying to other ports.

Take MS118CP as an example. If port 1, 2, 3, 4, 5 and 7 are consuming 28 W respectively, and an additional PoE device with 25 W is inserted to port 6, the system will cut off the power of port 7 to compensate for the overload.

### Q4. What should I notice before using the PoE Auto Recovery feature?

1. Before upgrading a connected PoE powered device (PD), disable PoE Auto Recovery to avoid the PD's damage.
2. When a PD does not send data packets to the switch for a long period in certain scenarios (e.g. an IPC in sleep mode), disable PoE Auto Recovery to avoid the PD repeatedly rebooting.

## Appendix B Specifications

Item	Content
Standards	IEEE 802.3i, IEEE 802.3u, IEEE 802.3ab, IEEE 802.3x
	IEEE 802.1p (Only for MS116GS/MS124GS)
	IEEE 802.3z, IEEE 802.3af, IEEE 802.3at (Except for MS116GS/MS124GS)
Transmission Medium	10BASE-T: 2-pair UTP/STP of Cat. 3 or above (maximum 100 m)
	100BASE-TX: 2-pair UTP/STP of Cat. 5 or above (maximum 100 m)
	1000BASE-T: 4-pair UTP/STP of Cat. 5e or above (maximum 100 m)
	1000BASE-LX (Only for MS120GP/MS126CP/MS128GP)
	1000BASE-SX/LX10/BX10 (Only for MS118CP/MS120GP/MS126CP/MS128GP)
Frame Forward Rate	10Base-T: 14881 pps/Port
	100Base-X: 148810 pps/Port
	1000Base-T: 1488095 pps/Port
	1000BASE-X: 1488095 pps/Port (Only for MS118CP/MS120GP/MS126CP/MS128GP)
LEDs	MS116GS: Power, Link/Act, 1000 Mbps
	MS124GS: Power, Link/Act
	MS118CP: PWR, Link/Act, PoE Status, PoE Max
	MS120GP: PWR, Link/Act, PoE Status, PoE Max
	MS126CP: PWR, Link/Act, PoE Status, PoE Max
	MS128GP: PWR, Link/Act, PoE Status, PoE Max
Power Supply	100-240VAC, 50/60Hz
Certification	CE, RoHS
Operating Temperature	MS116GS/MS124GS/MS118CP: -5 °C to 50 °C (23 °F to 122 °F) MS120GP: -10 °C to 50 °C (14 °F to 122 °F) MS126CP/MS128GP: -10 °C to 45 °C (14 °F to 113 °F)
Storage Temperature	-40 °C to 70 °C (-40 °F to 158 °F)
Operating Humidity	10% to 90% RH Non-condensing
Storage Humidity	5% to 90% RH Non-condensing



## CE Mark Warning



This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

## EU Declaration of Conformity

Mercusys hereby declares that the switch is in compliance with the essential requirements and other relevant provisions of directives 2014/30/EU, 2014/35/EU, 2011/65/EU and (EU)2015/863.

The original EU declaration of conformity may be found at <https://www.mercusys.com/en/ce/>

## UK Declaration of Conformity

Mercusys hereby declares that the switch is in compliance with the essential requirements and other relevant provisions of the Electromagnetic Compatibility Regulations 2016 and Electrical Equipment (Safety) Regulations 2016.

The original UK declaration of conformity may be found at <https://www.mercusys.com/support/ukca/>



Продукт сертифіковано згідно з правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України.

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。 VCCI-A

## Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Place the device with its bottom surface downward.
- The plug on the power supply cord is used as the disconnect device, the socket-outlet shall be easily accessible.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- Plug the product into the wall outlets with earthing connection through the power supply cord.
- The PoE ports shall not be used to charge lithium batteries or devices supplied by lithium batteries. (For MS118CP/MS120GP/MS126CP/MS128GP)
- The operating temperature for the device shall be within -5°C~50°C (23°F~122°F) for MS116GS/MS124GS/MS118CP, -10°C~50°C (14°F~122°F) for MS120GP, and -10°C~45°C (14°F~113°F) for MS126CP/MS128GP.
- 將設備底部朝下放置。
- 運作溫度:

MS116GS/MS124GS/MS118CP: -5°C~50°C (23°F~122°F)

MS120GP: -10°C~50°C (14°F~122°F)

MS126CP/MS128GP: -10°C~45°C (14°F~113°F)

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

This equipment is not suitable for use in locations where children are likely to be present.



## BSMI Notice

### 安全諮詢及注意事項

- 請使用原裝電源供應器或只能按照本產品注明的電源類型使用本產品。
- 清潔本產品之前請先拔掉電源線。請勿使用液體、噴霧清潔劑或濕布進行清潔。
- 注意防潮，請勿將水或其他液體潑灑到本產品上。
- 插槽與開口供通風使用，以確保本產品的操作可靠並防止過熱，請勿堵塞或覆蓋開口。
- 請勿將本產品置放於靠近熱源的地方。除非有正常的通風，否則不可放在密閉位置中。
- 不要私自拆開機殼或自行維修，如產品有故障請與原廠或代理商聯繫。

警告：為避免電磁干擾，本產品不應安裝或使用於住宅環境。

RoHS 限用物質聲明請查看：<https://www.mercusys.com/tw/support>（型號 / 技術支援）

## Explanation of the symbols on the product label


### 產品標籤上符號的解釋

Note: The product label can be found at the bottom of the product and its I.T.E. power supply. Symbols may vary from products.

注意：產品標籤可以在產品底部和其 I.T.E. 電源供應器上找到。產品標籤可在產品底部找到。符號可能因產品而異。

Symbol 符號	Explanation 說明
	Class II equipment 二級設備
	Class II equipment with functional earthing 具有接地功能的二級設備

	Alternating current 交流電
	Direct current DC 電壓
	Polarity of d.c. power connector 輸出端點的極性
	For indoor use only 僅供室內使用
	Dangerous voltage 危險電壓
	Caution, risk of electric shock 請注意, 有觸電的危險
	Energy efficiency Marking 能源效率標誌
	Protective earth 保護接地
	Earth 接地
	Frame or chassis 框架或外殼
	Functional earthing 功能接地
	Caution, hot surface 請注意, 表面過熱

	Caution 警告
	Operator's manual 操作手冊
	Stand-by 待機
	"ON"/"OFF" (push-push) “開啟” / “關閉” (按壓式)
	Fuse 保險絲
	Fuse is used in neutral N 保險絲用於中性線 N
	<p>RECYCLING 回收</p> <p>This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.</p> <p>User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.</p> <p>這個產品帶有歐盟指令 2012/19/EU 中關於廢棄電氣電子設備 (WEEE) 的選擇性分類標誌。這意味著, 該產品必須按照該指令處理, 以便進行回收或拆解, 從而最大限度地減少對環境的影響。</p> <p>用戶可以選擇將產品交給有資格的回收機構, 或在購買新的電器或電子設備時將其交給零售商進行回收。</p>
	Caution, avoid listening at high volume levels for long periods 請小心, 避免長時間以高音量收聽。
	Disconnection, all power plugs 斷線, 所有電源插頭

<b>m</b>	Switch of mini-gap construction 迷你間隙結構開關
<b>μ</b>	Switch of micro-gap construction (for US version) Switch of micro-gap / micro-disconnection construction (for other versions except US) 小間隙結構開關 (US 版本) 小間隙 / 小斷開結構的開關 (非 US 版)
<b>ε</b>	Switch without contact gap (Semiconductor switching device) 無接觸間隙的開關 (半導體開關設備)



For technical support, replacement services, and other information, please visit  
<https://www.mercusys.com/support/>.

© 2025 MERCUSYS 7100001530 REV1.4.0