

## Installation Guide

### Desktop Switch


\* MS108 is used for demonstration in this guide.

Images may differ from actual product.


© 2025 MERCUSYS 7100001535 REV1.1.0

### Connection Diagram

Connect the hardware according to the connection diagram.



### LED Explanation



### FAQ (Frequently Asked Questions)

**Q1. What should I do if the Power LED is off ?**

- A1: Make sure the power adapter is connected to the switch with power source properly.
- A2: Make sure the voltage of the power supply meets the requirements of the input voltage of the switch.
- A3: Make sure the power source is ON.

**Q2. What should I do if the Ethernet LED is off when a device is connected to the corresponding port?**

- A1: Make sure that the cable connectors are firmly plugged into the switch and the device.
- A2: Make sure the connected device is turned on and working properly.
- A3: The cable must be less than 100 meters long (328 feet).

## Français

Connectez le matériel conformément au schéma de connexion.

### Explication de la LED

Alimentation	On: le courant est allumé. Off: l'alimentation est éteinte.
Ports Ethernet	On: le port est connecté. Clignotant: le port envoie ou reçoit des données. Off: le port n'est pas connecté.

## Español (Latinoamérica)

Conecte el equipo de acuerdo con el diagrama de conexión.

### Explicación del LED

Alimentación	Encendido: La alimentación está encendida. Apagado: La alimentación está desconectada.
Puertos Ethernet	Encendido: El puerto está conectado. Parpadeo: El puerto está enviando o recibiendo datos. Apagado: El puerto no está conectado.

## Português Brasil

Conecte o hardware de acordo com o diagrama de conexão.

### Explicações sobre LEDs

Energia	Aceso: O dispositivo está ligado. Apagado: O dispositivo está desligado.
Portas Ethernet	Aceso: A porta está conectada. Piscando: A porta está enviando ou recebendo dados. Apagado: A porta não está conectada.

Para informações de aspectos de segurança e adequação do produto no território brasileiro consulte: [www.gov.br/anatel/pt-br/](http://www.gov.br/anatel/pt-br/)

## Türkçe

Donanımı bağlantı şemasına göre bağlayın.

### LED Açıklaması

Güç	Açık: Güç açıktır. Kapalı: Güç kapalı.
Ethernet Portları	Açık: Port bağlı. Yanıp sönüyor: Port veri gönderiyor veya alıyor. Kapalı: Bağlantı noktası bağlı değil.

## العربية

وصل الأجهزة بجهاز الكمبيوتر بالطريقة الموضحة في المخطط التوضيحي.

شرح حالة لمبات LED في الجهاز

مضينة: الجهاز يستقبل الطاقة ويعمل.	الطاقة الكهربائية
غير مضينة: الجهاز لا يستقبل الطاقة ومغلق.	
مضينة: المنفذ متصل.	
تضيء وتطفئ: ترسل البيانات أو تستقبل عبر المنفذ.	منافذ اتصال الإيثرنت
غير مضينة: المنفذ غير متصل.	

Arabic Translated By:  
EGY TRANSCRIPT FOR TRANSLATION  
Tel: +20 2 3762 9100

### Safety Information

- Keep the device away from water, fire, humidity or hot environments.
  - Do not attempt to disassemble, repair, or modify the device, if you need service, please contact us.
  - Do not use damaged charger or USB cable to charge the device.
  - Do not use any other chargers than those recommended.
  - Place the device with its bottom surface downward.
  - Adapter shall be installed near the equipment and shall be easily accessible.
- Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of device. Please use this product with care and operate at your own risk.



For technical support, the user guide and more information, please visit <http://www.mercusys.com/support/>.