

# How to upgrade MERCUSYS Range Extender

## Part A: Please read this section carefully before upgrade

1. Please verify the hardware version of your device for the firmware version. Wrong firmware upgrading may damage your device and void the warranty.



MW300RE(EU)\_V3\_180306 ↓

Published Date: 2018-06-19

Language: English

File size: 932 KB


2. After you downloaded the firmware from MERCUSYS website, please use decompression software such as WinZIP or WinRAR to extract the firmware file to a folder, the firmware is usually named as XXXX.bin.

3. **Do NOT** turn off the power or disconnect the wireless during upgrade process.

4. It's recommended that users stop all Internet Applications on the computer, or simply disconnect Internet line from the device before upgrade.

## Part B: Please follow the steps below to upgrade firmware version

1. Log into the MERCUSYS device by typing <http://mwlogin.net/> in the address bar of the web browser (such as Google Chrome, Firefox). Please input the password you preset.



2. Click Advanced > System Tools > Firmware Upgrade, click the Browse button to choose the

bin firmware you already extracted in the folder.

## Firmware Upgrade



Select your upgrade file, then click Upgrade.

Browse

Upgrade

Hardware Version: MW300RE 3.0 00000000

Firmware Version: 1.0.0 Build 171130 Rel.33685n

3. Click the Upgrade button. The device will reboot automatically after the upgrading has been finished. Please wait about 3~5 minutes.

4. Check the lower right corner of the webpage or the device info of Firmware Upgrade page, verify that the router's firmware has been upgraded.

Hardware Version: MW300RE 3.0 00000000

Firmware Version: 1.0.0 Build 180306 Rel.33685n

Firmware Version: 1.0.0 Build 180306 2345n

Mercusys Official Website