

How to upgrade MERCUSYS Wireless Router

Part A: Please read this section carefully before upgrade

1. Please verify the hardware version of your device for the firmware version. Wrong firmware upgrading may damage your device and void the warranty.



MW305R(EU) V2_180228 ↓

Published Date: 2018-03-27

Language: English

File size: 1.19 MB

2. After you downloaded the firmware from MERCUSYS website, please use decompression software such as WinZIP or WinRAR to extract the firmware file to a folder, the firmware is usually named as XXXX.bin.
3. Do NOT upgrade the firmware via wireless connection unless there is no LAN/Ethernet port on your Mercusys device.
4. Do NOT turn off the power or disconnect the Ethernet cable during upgrade process;
5. It's recommended that users stop all Internet Applications on the computer, or simply disconnect Internet line from the device before upgrade.

Part B: Please follow the steps below to upgrade firmware version

1. Log into the MERCUSYS device by typing <http://mwlogin.net/> in the address bar of the web browser (such as Google Chrome, Firefox), as shown below. Please input the password you preset.



2. Click Advanced > System Tools > Firmware Upgrade, click the Browse button to choose the firmware you already extracted in the folder.

Firmware Upgrade ?

Select your upgrade file, then click Upgrade.

Hardware Version:
Firmware Version:1.0.0 Build 180101 Rel.12345n

3. Click the Upgrade button. The device will reboot automatically after the upgrading has been finished. Please wait about 3~5 minutes.
4. Check the lower right corner of the webpage or the device info of Firmware Upgrade page, verify that the router's firmware has been upgraded.

Hardware Version: MW325R 2.0 00000000
Firmware Version:1.0.0 Build 180228 Rel.12345n

Firmware Version:1.0.0 Build **180228** 2345n Mercusys Official Website