


How to upgrade Mercusys ADSL Modem Router


Notice:

- **Please verify the hardware version of your device for the firmware version. Wrong firmware upgrading may damage your device and void the warranty.**




- **After you downloaded the firmware from Mercusys website, please use decompression software such as WinZIP or WinRAR to extract the firmware file to a folder;**
- **Do NOT upgrade the firmware via wireless connection unless the device does not have cable connection;**
- **Do NOT turn off the power or cut down the Ethernet cable during upgrade process;**
- **Write down all the settings which you changed from the default values, since you may need to reenter them manually.**

Step 1 Log into the ADSL Modem Router by typing **http://192.168.1.1** in the address bar of the web browser (such as Chrome, Firefox). **The UserName and Password are both admin** unless you have changed it before.




Step 2 Click **Maintenance** ->**Firmware** click the **Browse** button to choose the firmware you already extracted in the folder.




Step 3 Click the **UPGRADE** button. The device will reboot automatically after the upgrading has been finished. Please wait about 3 minutes.

Step 4 Click **Status**-> **Device Info**, verify that the router's firmware has been upgraded.



Step5 You have to restore the device to factory default to make the new functions take effect; Click **Maintenance**->**SysRestart**, choose **Factory Default Settings**, Click **RESTART** button.



Step 6 After restoring factory default, please login <http://192.168.1.1> and re-enter the settings you have written down before upgrading.