MERCUSYS®

Quick Installation Guide

Wireless USB Adapter

1 Connect to a Computer

Option 1: Directly

Option 2: Via the USB Extension Cable (If provided)

2 Install Driver

Follow **Method 1** if Driver CD is contained in your product package. If not, please try **Method 2**.

- **Method 1: via Driver CD**

a. Insert the CD and run the setup program manually.

   Note:
   If there is no available CD drive on your computer, You can also download the latest driver at www.mercusys.com/support.

b. Follow the pop-up instructions to complete the installation.

- **Method 2: via Internal Driver Installation**

a. Go to **My Computer** or **This PC**.

b. Find out **Mercusys** disk then run the **SetupInstall.exe** to start driver installation.

   Note:
   If you cannot find the **Mercusys** disk, download the driver at www.mercusys.com/support.

c. Follow the instructions to complete the installation.

3 Join a Wireless Network

a. Click the network icon (🖳) on the taskbar.

b. Select your Wi-Fi network, click **Connect** and enter the password when prompted.

Troubleshooting

If you have problems during the installation, please refer to the following online FAQs.

T1. Check if the driver is successfully installed:
https://www.mercusys.com/faq-262

T2. How to Manually Install / Update Adapters on Windows 7: https://www.mercusys.com/faq-263

T3. How to Manually Install / Update Adapters on Windows 8: https://www.mercusys.com/faq-261

T4. How to Manually Install / Update Adapters on Windows 10: https://www.mercusys.com/faq-265

Support

For technical support, the user guide and more information, please visit https://www.mercusys.com/support.